# 2011 DoD Environmental Monitoring and Data Quality (DoD EMDQ) Workshop

# RDX Transformation In Biotic and Abiotic Systems Under Poised Redox Potentials

Ms. Deborah Felt
U.S. Army Engineer Research and
Development Center




maintaining the data needed, and c including suggestions for reducing	lection of information is estimated to completing and reviewing the collect this burden, to Washington Headqu uld be aware that notwithstanding an DMB control number.	ion of information. Send comments arters Services, Directorate for Infor	regarding this burden estimate or mation Operations and Reports	or any other aspect of the 1215 Jefferson Davis	nis collection of information, Highway, Suite 1204, Arlington	
1. REPORT DATE 30 MAR 2011	2. REPORT TYPE		3. DATES COVERED <b>00-00-2011 to 00-00-2011</b>			
4. TITLE AND SUBTITLE				5a. CONTRACT	NUMBER	
RDX Transformat	oiotic Systems Under	r Poised Redox	5b. GRANT NUMBER			
Potentials			5c. PROGRAM ELEMENT NUMBER			
6. AUTHOR(S)				5d. PROJECT NUMBER		
				5e. TASK NUMBER		
				5f. WORK UNIT NUMBER		
U.S. Army Engine	ZATION NAME(S) AND AE er Research and Dev Ialls Ferry Road,Vio	velopment Center,E		8. PERFORMING REPORT NUMB	G ORGANIZATION ER	
9. SPONSORING/MONITORING AGENCY NAME(S) AND ADDRESS(ES)				10. SPONSOR/MONITOR'S ACRONYM(S)		
				11. SPONSOR/MONITOR'S REPORT NUMBER(S)		
12. DISTRIBUTION/AVAIL Approved for publ	LABILITY STATEMENT ic release; distributi	on unlimited				
13. SUPPLEMENTARY NO Presented at the 20 1 Apr, Arlington, V	11 DoD Environme	ntal Monitoring & I	Data Quality Wo	rkshop (EMI	OQ 2011), 28 Mar ?	
14. ABSTRACT						
15. SUBJECT TERMS						
16. SECURITY CLASSIFICATION OF:			17. LIMITATION OF	18. NUMBER	19a. NAME OF	
a. REPORT unclassified	b. ABSTRACT unclassified	c. THIS PAGE unclassified	Same as Report (SAR)	OF PAGES 22	RESPONSIBLE PERSON	

**Report Documentation Page** 

Form Approved OMB No. 0704-0188

#### **Background**

- Hexahydro-1,3,5-Trinitro-1,3,5-triazacyclohexane (RDX) is present in soils due to training and other activities
- In situ techniques exist to degrade RDX
- RDX degradation could be enhanced if biogeochemical factors could be determined and/or controlled.
- Purpose was to determine the role redox potentials play in RDX degradation.



Redox potentials for common environmental electron accepting processes



#### **Hypothesis**

Biological processes of nitrate, iron, and sulfate-reducing bacteria create conditions conducive not only to direct enzymatic RDX transformations, but also to indirect abiotic RDX degradation.



#### Approach-3 test systems

- 1. **Biological**: Mixed consortium amended with terminal electron acceptor and RDX. Controls did not contain inoculum.
- 2. **Biologically poised (abiotic**): Biological cultures with terminal electron acceptor were grown until Eh was reduced (30 days). Cultures were autoclaved and amended with RDX. Controls did not contain inoculum.
- 3. **Chemically poised**: RDX solutions containing terminal electron acceptor. Eh of solutions were chemically reduced. RDX in a buffer solution was control.

#### Approach-continued

#### **Mixed Culture**:


- Pseudomonas aeruginosa nitrate reducer
- Geobacter metallireducens GS-15 iron reducer
- Desulfovibrio desulfuricans G20 sulfate reducer

#### **Nutrient broth:**

- Electron acceptor: Fe<sup>3+</sup>, NO<sub>3</sub>-, or SO<sub>4</sub><sup>3-</sup> at 10 mM
- RDX at 1 or 4 ppm (5 and 20 μM)
- Buffered to maintain pH 7.
- Initial ORP= 300mV
- N-Tris(hydroxymethyl)methyl-2-aminoethanesulfonic acid
  - ▶ Buffer for Biotic cultures
- tris(hydroxymethyl) aminomethane
  - ▶ Buffer for chemically poised systems

#### **Analysis**


- Explosives (HPLC)
- pH: pH electrode
- Eh: Pt electrode and Ag Cl reference
- Amendments: IC
- Organic transformation products (HPLC-ESI-MS)







### **Biological RDX reduction**

RDX concentration (ppm) versus time (days)








RDX was degraded under all three conditions in the biological systems.

BUILDING STRONG®

#### Kinetics of biological RDX reduction



For first-order rate kinetics analysis: C=C<sub>0</sub>e<sup>-kt</sup> in which: C= concentration mg/L k=reaction rate per day t= time in days

Linearization yields In  $(C_0/C)$ =kt


	Iron	Sulfate	Nitrate
k, per day	0.1152	0.1126	0.0613
Half life, days	6.01	6.15	11.31

**First Order Rate Kinetics** 




#### **Abiotic RDX reduction**

Eh was reduced by biological activity, autoclaved, and amended.



#### Kinetics of abiotic RDX reduction

Biotic degradation was much faster—rates are at least 4X abiotic rates



For first-order rate kinetics
analysis: C=C<sub>0</sub>e<sup>-kt</sup>
in which:
C= concentration in mg/L
k = reaction rate per day
t = time in days

#### **First Order Rate Kinetics**

	Iron	Sulfate	Nitrate
k, per day	.0017	.027	.0143
Half life, days	407.7	25.7	48.5
Half life, biological reduction	6.01	6.15	11.31



#### **Chemically poised systems**

- Iron (II) as the reductant
- Sulfur/Sulfide as the reductant
- Nitrogen compounds as the reductant





#### Iron System

- Used 2 mM Iron (II) solutions in Tris Buffer with a Tiron ligand at pH 7.5-8
  - ► Ferrous Sulfate Fe(II)
  - ► Ferric Sulfate Fe(III)

Iron-facilitated abiotic degradation of RDX only occurs under anaerobic conditions.

Tiron



#### **Iron System**

Iron Species	рН	Eh	RDX Degradation		
Single Iron Solution	Single Iron Solutions				
Fe (II)	7.58	-240	Yes		
Fe (II)	7.62	-268	Yes		
Fe (II)	7.71	-201	Yes		
Fe(III)	7.61	-220	No*		
Mixed Iron Solutions (50: 50):					
Fe(II):Fe(III)	7.72	-223	Yes		
Fe(II):Fe(III)	7.68	-255	Yes		

- Iron (II) was a successful reductant for RDX
- Iron (III) exhibited minimal potential for RDX degradation
   Iron facilitated RDX degradation is most likely to occur in reducing environments (< -150 mV)</li>

#### Sulfur/Sulfide Systems

The effectiveness of Sulfur/Sulfide as a reductant were evaluated using:

- H<sub>2</sub>S bubbled Tris buffer solution
- Elemental Sulfur
- Dithiolbenzene (DBT)
- Sodium Sulfate
- Sodium Sulfide

dithiolbenzene



## Sulfur/Sulfide Systems

DBT Experiment	рН	Eh	RDX Degradation
DBT alone			
	8.3	-136	Yes
	8.5	-92	Partial
DBT + Iron			
	8.5	-477	Yes
	8.5	-380	Yes
	9	-467	Yes
	9	-403	Yes

- Dithiolbenze is effective at abiotically degrading RDX
- It is highly effective in the presence of Iron (II)



#### Nitrogen Systems

The effectiveness of Nitrogen as a reductant was evaluated using:

- 1.5 mM Hydroxylamine
  - ▶ pH/Eh: 3.9/-180; 6.0/-195; 8.0/-256
- 1 mM Sodium Nitrite
  - ► pH/Eh: 8.0/-238
- 1 mM Sodium Nitrate
  - ► pH/Eh: 5.0/-246; 7.1/-261; 8.0/-266

## RDX did not degrade in the presence of these N- compounds

#### **Summary of Chemically Poised tests**

- We found iron to be effective at very low Eh values and under anaerobic conditions.
- Sulfur can also be an effective reductant (depending on its form). Sulfides cause degradation, while sulfates and elemental sulfur does not.
- The nitrogen compounds used did not cause RDX degradation under these experimental parameters.

## Eh – pH Comparison

		Iron	Sulfate	Nitrate
Biologica	a <b>l</b> Eh	-63mV	-154 mV	-237 mV
	рН	7	7	7
Abiotic	Eh pH	-30 mV * 7-8	-230 mV 7-8	-215 mV 7-8
Chemica Poised	<b>lly</b> Eh	< -150 mV	-150 mV (DTB) -400 mV (DTB-Fe)	-60 mV *
	рН	7.5 - 8	6 – 8.5	6 -8

<sup>\*</sup> Indicates that RDX did not degrade in this system



#### Conclusions

- Original hypothesis: Biological processes of nitrate, iron, and sulfate-reducing bacteria create conditions conducive not only to direct enzymatic RDX transformations, but also to indirect abiotic RDX degradation.
- Abiotic degradation takes place under nitrate and sulfate reducing conditions that were initiated by a bacterial consortium. Abiotic iron systems did not efficiently degrade RDX.
- Abiotic degradation is much slower than biological degradation.
- RDX degraded in systems that were at neutral pH and generally at Eh values < -150 mV. Fe biological system was exception.



#### **Project Team**

- ▶ Dr. Heather Smith ERDC-EL
- ▶ Dr. Jennifer Seiter ERDC-EL
- ▶ Dr. Anthony Bednar ERDC-EL
- ► Mr. Clint Arnett ERDC-CERL
- ► Deborah Ragan Badger Technical Services



## Thanks for your attention!



#### Sulfur/Sulfide Systems

- Results show that elemental sulfur alone did not result in degradation of RDX at neutral pHs.
  - ▶ pH/Eh: 7.0/-280; 8.0/-285
- 10 mM Sodium Sulfate did not cause RDX degradation
  - ► pH/Eh: 4.8/-258; 7.1/-270; 8.0/-275
- 100 mM Sodium Sulfide effectively degraded RDX at a pH of 12, and partially degraded it at pHs 8 and 10.
  - ▶ pH/Eh: 8.0/-351; 9.9/-355; 12/-361



#### **Lessons Learned**

- ► RDX can degrade abiotically under anaerobic conditions that were mediated by biological processes
- ► Abiotic rates are slower than biological rates
- Abiotic RDX degradation rates follow sequence  $SO_4^{-2} > NO_3^{-2} > Fe^{+2}$
- ► Eh values in effective systems were usually <-150 mV, in neutral solutions. Fe biological system was unique.
- ► RDX was not degraded until after nitrate was depleted Eh value is not low enough.

